



INSTALLATION MANUAL



Part 1. Exchanging LED module



FULLA S HE X-FLIP



AC220-240V | 50/60Hz | IP20 | Die cast | Adjustable



Do not operate with power supply connected.

1  Wear gloves to protect the reflector.	2  Unscrew the front ring.	3  Take out the reflector by turning it counterclockwise.
4  Remove the module by turning it counterclockwise.	5 Ensure correct positioning.  Insert and secure the new module by turning it clockwise.	6 Ensure correct positioning.  Install the reflector by turning clockwise.
7  Secure front ring.		

Warnings:

1. Make sure that the product is installed properly before connecting to electricity.
2. Do not cover the fitting.
3. Maintenance and installation should only be carried out by a professional electrician.



INSTALLATION MANUAL



Part 2. Installing the luminaire



FULLA S HE X-FLIP



AC220-240V | 50/60Hz | IP20 | Die cast | Adjustable



Do not operate with power supply connected.

1	2 Open a Ø140mm diameter hole in the ceiling.	3 Connect the power supply (AC220-240V).
4 Pull on the sketch clamp along the arrow direction.	5 Clip upward and place the product in the hole in the ceiling.	6 The installation is complete.
7 Switch on the power, lighting.	8	

Warnings:

1. Make sure that the product is installed properly before connecting to electricity.
2. Do not cover the fitting.
3. Maintenance and installation should only be carried out by a professional electrician.