





INSTALLATION MANUAL











HUGINN L



AC220-240V | 50/60Hz | IP20 | Die cast



Do not operate with power supply connected.

<p>1</p>  <p>To mount the track adaptor into the track system, first check that the selector knob A is at OFF position and the adaptor lock B is disengaged.</p>	<p>2</p>  <p>When installing the adaptor into the track, ensure that it is orientated correctly.</p>	<p>3</p>  <p>Rotate adaptor lock B clockwise to connect the adaptor to the neutral circuit.</p>
<p>4</p>  <p>Rotate selector knob A to the position of desired circuit.</p>	<p>4a</p>  <p>Circuit 1: Rotate the knob A clockwise from the starting position OFF, to connect circuit 1.</p>	<p>4b</p>  <p>Circuit 2: Rotate the knob A counter-clockwise from the starting position OFF, to connect circuit 2.</p>
<p>4c</p>  <p>Circuit 1: Rotate the knob A clockwise from the starting position OFF, to connect circuit 3.</p>	<p>5</p>  <p>350° 90°</p>	

Warnings:

1. Make sure that the product is installed properly before connecting to electricity.
2. Do not cover the fitting.
3. Maintenance and installation should only be carried out by a professional electrician.