






INSTALLATION MANUAL



FORSITE 1150 SM




AC220-240V | 50/60Hz | IP20 | Extruded




Do not operate with power supply connected.

1




OFF

turn off power
before installation.




The lamp body is equipped with a mounting bracket

2




Ceiling

Connect
Cable




3




Ceiling

Fixing bracket



4




ceiling

Linear Light

ON

Turn on the power



Warnings:

1. Make sure that the product is installed properly before connecting to electricity.
2. Do not cover the fitting.
3. Maintenance and installation should only be carried out by a professional electrician.